



### FEATURES

- One high impact plastic shelf.
- Attaches to cabinet shelf or bottom.
- 18" diameter White colored shelf.
- Fits 30", 36", 42" high WC, WCMGD and WDFC wall cabinets.

### PARTS LIST

- Cap
- Shaft
- Shaft Locking Screw
- Shelf and Shelf Support
- Bottom Positioner Assembly

### TOOLS REQUIRED

- Electric Drill
- 1/8" Drill Bit
- Screwdriver

## Lazy Susan Kit (1 shelf) Installation Instructions

**Step 1** Locate the bottom positioner assembly on the cabinet floor so that the shelf will have at least 3/8" side clearance all around.

**Step 2** Pilot drill (1/8" dia.) holes and fasten the positioner assembly with four (4) 3/4" x 8 oval head wood screws. (The tapping screws may be discarded).

**Step 3** Insert the shaft into the positioner assembly and tighten the locking screw. Place the shelf onto the shaft and snap cap into the top of the shaft.

